



# ИНСТРУКЦИЯ ПО МОНТАЖУ ABBER Schwarzer Diamant

AG30100BH/AG30110BH/AG30120BH/AG30130BH/AG30140BH/  
AG30150BH/AG30160BH/AG30170BH



## НЕОБХОДИМЫЕ ИНСТРУМЕНТЫ



## СПИСОК ДЕТАЛЕЙ

X2	X1	X1	X2	X2	X2	X2
X2	X1	X2	X1	X1	X2	X8
4X30	X16	4X16	X4	4X10	X2	4X12
				X4	$\Phi 3.2$	X1

1

РАЗМЕР	A(мм)
1000	990-1020
1100	1090-1120
1200	1190-1220
1300	1290-1320
1600	1590-1620
1700	1690-1720

2

3

4

5

6

